

External

Hot Press / Plant Room

Notes

This diagram is intended for use in Ireland as an overview of connection terminals and cable sizes for use on site.

Please refer to the manufacturers Installation Guide for full electrical details and guidance.

All connections should be verified for polarity by a qualified electrician.

Full Installation Guide



Training Videos



Ideal Energy Distribution Ltd.

Drawn By	Odhran Casey
Date	16/10/26
Drawing	Pre Plumbed Control Box

